



1/1/2018

SAP Board Installation Instructions

1. Always use proper Safety Equipment and Personal Protective Equipment
2. Ensure framing and trusses are square & level
3. All permanent bracing should be installed
4. Apply a continuous $\frac{1}{4}$ " bead of adhesive to top of truss
5. Two beads of adhesive are required on shared trusses
6. Space SAP boards on staggered centers
7. #8 x 3" fasteners are to meet ICC-ES ESR-1472
8. Ensure fasteners fully penetrate surface of the panels
9. SAP board tongue & groove allows for $\frac{1}{16}$ " gap between boards
10. Ensure space between panels is equal on all four sides
11. Ensure tongue fully engages groove as indicated
12. Fasteners are to be installed on 6" center at the ends and 12" on center in field
13. Always install all fasteners when adhesive is uncured
14. Install perimeter fasteners first
15. Ensure specified spacing is maintained and refer SAPboard Structural Drawing
16. Always drill plumbing and electrical holes requires as floors are constructed
17. Finish flooring contractor should be sure all fastener heads are seated and remove any high points during floor prep